

Use the following table of resistance and current values to solder the right resistor to obtain the required current:

<b>Adjust Charge Current</b>	
<b>RPROG (k)</b>	<b>IBAT (mA)</b>
<b>30</b>	<b>50</b>
<b>20</b>	<b>70</b>
<b>10</b>	<b>130</b>
<b>5</b>	<b>250</b>
<b>4</b>	<b>300</b>
<b>3</b>	<b>400</b>
<b>2</b>	<b>580</b>
<b>1.5</b>	<b>780</b>
<b>1.2</b>	<b>1000</b>

